


Wonder®

TEXTILE CLEANING SPRAY GUNS

PARTS LIST FOR TS16 / TS16A



Part #	Item
1	Gun Housing
2	Gun Housing Cap
3	Inductor Coil (220V/50Hz, Coil Only)
4	Trigger Switch Assembly
5A	I Core
5B	E Core with Coil
6	Electric Wire
7	Buffer Nut
8	Pressure Control Knob
9	Pressure Control Knob Spring

Part #	Item
10	Coil Spring
11	Coil Pin
12	Gun Housing Screws (2 pcs)
13	Pump Cylinder
14	Piston
15	Piston Spring
16	Coil Locking Pin
17	Delivery Valve Cone
18	Delivery Valve Spring
19	Swirl Head (17, 18, 19 Form a Set)

Part #	Item
20	Nozzle - Straight
20A	Nozzle - Adjustable
21	Solvent Jar
22	Suction Pipe With Filter
23	Conical Screw
24	Connector Block
25	Overflow Tube
26	Coil Bush
27	Switch Locking Ring